

# Commissioning Training CF210



Lab & Pilot Equipment

Carbo-Fill Carbonator



- **Introduction**
- **Saturation**
- **Working Principle**
- **Operation**
- **Foamy products**
- **Beer processing**
- **Technical information**



## Carbonisation



Solubility depends on temperature and pressure

lower T (°C) → higher solubility

higher P (bar) → higher solubility

## Other influences on CO<sub>2</sub> solubility

- Ingredients, e.g. sugar or wort


## Beverages

CO<sub>2</sub> solubility changes per Brix about 1%, e.g. a sugar content of 8 Brix results in 8% lower CO<sub>2</sub> solubility than in water


## Beer

CO<sub>2</sub> solubility changes per 3° Plato about 1%, e.g. a original wort of 9° Plato results in 3% lower CO<sub>2</sub> solubility than in water

The **saturation** is being performed by a sinter tube, a metal cylinder with very small holes



# Working principle




Saturation content of the product based on **temperature** and **pressure** in the saturation vessel

Filling product due to pressure difference between the vessel and the surrounding atmosphere


Post mix and pre-mix processing

# Working principle






# Working principle



## Filling head




## Measuring CO<sub>2</sub>

Commonly used method to determine the CO<sub>2</sub> content is based on Henry's Law. Determine pressure and temperature in bottle after shaking.


### Influence on the measurements

- Headspace
- Material of the bottle
- Filling parameters
- Etc.

Carbo-Fill is operated by a touch-screen.



## Main menu



## Processing – carbonisation parameters

The screenshot displays the 'Processing' screen of a CF210 device. The interface includes a green header bar with the word 'Processing' in white. On the left side, the model number 'CF210' is printed vertically. The main area contains two input fields for 'Project name:' and 'Description:'. At the bottom left, there is an 'Alarm description:' label above an empty text box. On the right side, there are two buttons: 'Settings' (with a numeric keypad icon) and 'Recipes' (with a notepad icon). At the bottom right, there are three buttons: 'NEXT', 'Reset', and 'STOP'. A faint 'omve' logo is visible in the background.

Processing

CF210

Project name:

Description:

Alarm description:

Settings

Recipes

NEXT

Reset STOP

## Processing – carbonisation parameters

**Processing**

**Carbonation Settings**

Temperature  C

Pressure  bar

Gas type

**Carbonation Mode**

**Closing Mode**

**Preset pressure**

bar

**Prev** **Next**

Alarm description:

**Settings**

**Recipes**

CF210

## Processing – carbonisation parameters

CF210

Processing

Filling settings

Fill Time	1.5 sec.
Depress Time	10.0 sec.
Clear Overflow	4.0 sec.
Flush Time	5.0 sec.
Pressurize Time	2.4 sec.
Level Out Time	0.0 sec.

Prev

START

Alarm description:

Reset

STOP

Settings

Recipes



## Processing – recipes

**CF210**

**Project**  
Project name: hallo 1  
Description: 3

# Processing

### Carbonation Settings

Temperature: 0.0 C  
Pressure: -1.0 bar  
Gas type: CO2  
Carbonation Mode: Batch Product  
Closing Mode: Filling Only

### Filling settings

Fill Time: 000.0 sec.  
Depress Time: 000.0 sec.  
Clear Overflow Time: 000.0 sec.  
Flush Time: 000.0 sec.  
Pressurize Time: 000.0 sec.  
Level Out Time: 000.0 sec.

Recipe ID: 0    Prev    Next

Save    Load

Alarm description:

Reset


View

Trends


Settings

Recipes


## Processing – overview





## Processing – trends



## Cleaning



## Cleaning



Cleaning – programs

Empty machine:

Emptying tank

Rinse machine:

Emptying tank, flushing tank with tap water, emptying tank

## Cleaning – programs

### Clean machine complete:

Emptying tank, flushing tank with tap water and empties again, flushes with manually pored (hot) cleaning fluid and empties again, rinses with water and empties again.

## Service

CF210

Service

Counters

Operation hours	91 h.
On/Off's	16
Filled bottles (odo)	291
Filled bottles (batch)	265

Reset

Test mode

Bottle lift

Fill

↑

↓

Screw

↺

Capper

Forward

←

Back

→

EXIT

↑



Foamy products

**Examples: Beer, Dairy drinks, Beverages**

## **How to prevent foam in general**

- Prevent big changes in pressure and temperature.
- Prevent high product flows.
- Prevent contact with oxygen.
- Give the product time to settle down.

## Foamy products

### **How to prevent foam in the saturation vessel:**

- Pressure on CO2 supply regulator approximately 1 bar higher than desired pressure level.
- Cool down the vessel by cooling it down with water.
- Optional: remove the inner tube of the saturation vessel.


## Foamy products

### **How to prevent foam in the bottle**

- Use low filling speeds.
- Increase Level Out time and Sniff time.
- Use the shield on filling tube.
- Use clean bottles.
- Use cold bottles.

## Beer processing

### Set-up for beer processing



## Beer processing

### **Beer processing procedure**

1. Fill the saturation vessel with water and cool it down to 4 degrees.
2. Empty the vessel with N2.
3. Remove Oxygen by flushing the system with CO2.
4. Fill the saturation vessel slowly with beer.

## Beer processing

5. Cool the beer to the desired temperature.
6. Stabilise the beer for 5 minutes.
7. Open the CO<sub>2</sub> supply slowly.
8. Increase the CO<sub>2</sub> pressure by steps of 0.1 bars and let the beer stabilise for 5 minutes after each step.
9. Saturate the beer.
10. Fill the bottles.

Beer processing - example filling and carbonisation parameters:

Temperature	8.0	°C
Pressure	1.5	bar
Filling time	36.0	s
Sniff time	22.0	s
Clear Overflow time	1.5	s
Flushing time	2.0	s
Pressurizing time	2.0	s
Level out time	6.0	s
Filling speed valve	2.5	turn
CO2 supply pressure	2.6	bar

## Utilities

Utility	Flow/Amount	Pressure	Temperature	Connection type	Remarks
Main water supply		Max 2.5 bar	Max 20 °C	Serto Hose ferrule	Protect against water hammering
CO <sub>2</sub>		Max 3,5 bar		Serto Hose ferrule	Add a manometer; 6 bar
N <sub>2</sub> (optional)		Max 3.5 bar		Serto Hose ferrule	Add a manometer; 6 bar
Compressed air		4-7 bar		Serto Hose ferrule	
Drains			Max 70 °C	Serto Hose ferrule	Open connection. Do not combine
Electricity	220-240V / 50-60 Hz, grounded				



## Utilities

- CO<sub>2</sub> gas supply with a, non-flow restricting, pressure regulator (max. 3,5 bar)
- N<sub>2</sub> supply (optional) with pressure regulator (max. 3,5 bar).

DO NOT USE A FLOW REGULATOR

## Maintenance

The following parts are subjected to wear

- Inner parts valves
- Seals filling head



Lab & Pilot Equipment

# Thank you!

[Name engineer]

[e-mail engineer]

[support@omve.com](mailto:support@omve.com)